Extraction Fan/Air Mover– Instructions for use

PRE-START CHECK:

- Make sure unit is switched off before connecting to the power source.
- Ensure extension lead is no longer than 15ms.
- Check that immediate area in front & behind the fan are clear.

SAFETY PRECAUTIONS:

- Turn unit off before shifting or changing ducting.
- It is best to remove ducting before shifting unit to avoid any damage.
- Wait for the fan blades to stop before shifting or removing ducting.

OPERATION:

- Set up in desired position to either extract or move air.
- Connect ducting if using fan for extraction.
- Check area near fan for debris or anything that could be sucked in & blown out or cause damage.
- Connect to power & swich unit on.

REQUIRED SAFETY EQUIPMENT:


Hearing Protection


Foot Protection

STOPPING AND AFTER USE:

- Switch off at unit.
- When fan blades have stopped unplug the unit.
- Remove ducting if used.
- Wipe unit clean.

If you are collecting the equipment for someone else please make sure this sheet is given to them. If the equipment is being hired for commercial use it should be given to the site supervisor to ensure it is available to all users.