

Plate Compactor Reversible – Instructions for use

PRE-START CHECKS:

- Ensure the work area is clear of any obstacles, steep gradients or uneven ground.
- Use extreme caution & always be aware of ground subsidence with compaction vibration transfer.

OPERATION:

- Turn ignition switch to ON position.
- Move throttle lever to half throttle.
- Ensure the **forward/reverse** lever is in the neutral position.
- Turn ignition switch to pre-heat & hold for 10 seconds then start the machine.
- Move throttle lever to the idle position & allow to warm up.
- Hold compactor firmly with both hands.
- Move throttle lever to desired speed. **Note** – Max compaction is achieved with full throttle.
- Proceed to move compactor around area to be compacted by moving the forward/reverse lever in the desired direction.
- At the end of the compaction line move the **forward/reverse** lever in the opposite direction or neutral to stop (**if you choose to stop ensure you lower the throttle speed as well otherwise the unit will continue to vibrate**).

STOPPING AND AFTER USE:

- Idle the engine.
- Turn ignition switch of OFF.

SAFETY PRECAUTIONS:

- Hold compactor with both hands.
- Make sure you have a firm footing when operating.

REQUIRED SAFETY EQUIPMENT:

