

# Rotary Hoe (small)- Instructions for use

# FOR TILLING ONLY (SOFT OR PREVIOUSLY TILLED GROUND)

## **PRE-START CHECKS:**

 Ensure area to till is free of all rubble and debris.

# **STOPPING AND AFTER USE:**

- Move throttle lever to idle.
- Turn the ignition switch to off.

# **STARTING PROCEDURE:**

- Turn ignition switch to run.
- Engage choke.
- Move throttle to start position.
- Pull starter briskly to start the engine.
- Disengage choke and allow the engine to warm up.

# **OPERATION:**

- Note: the clutch is engaged by pulling in the lever (this starts and stops the tine rotation)
- The depth is determined by how much pressure is applied on the handles.
- Increase engine speed to the desired position.
- Should the machine jerk forward while tilling, press down on the handlebars.

# **SAFETY PRECAUTIONS:**

- Stop engine to refuel.
- Stop engine to clear tines.
- Do not touch hot engine.

## **HAZARDS**:

- Keep children clear of working area.
- Keep hands and feet clear of tines while machine is running.

# **FUEL:**

Unleaded 91

## **REQUIRED SAFETY EQUIPMENT:**







Protection





If you are collecting the equipment for someone else please make sure this sheet is given to them. If the equipment is being hired for commercial use it should be given to the site supervisor to ensure it is available to all users.